



- Adjustment procedure:**
1. FET Bias: With Osc. Ampl. trimmer fully counterclockwise, adjust FET Bias so that audible phasing sound is in the middle of its range.
  2. Osc. Ampl.: Adjust for desired depth of phasing sound.
  3. Output Offset: adjust for minimum "click" when Off/Slow Phase switch is operated.