



- V4B unused**
- (X-V) DENOTES CHANNEL SELECTED. CH-2 VOLUME, IN TO SELECT CH-1, OUT TO SELECT CH-2. (WITH FOOTSWITCH NOT CONNECTED.)
 - ▲ USE 9N Q14700 ONLY FOR REPLACEMENT EXCEPT THOSE VERSIONS WHICH USE 9N Q18764 .01/125 V.A.C. (NO SUBSTITUTION).
 - DENOTES DC VOLTAGES, WITH NO OUTPUT, WITH 20,000 OHMS PER VOLT MULTIMETER.
 - 2 ALL CAPACITORS 600 V. MIN.
 - 1 ALL RESISTORS 1/2 WATT ±10%.
 - (M.V) DENOTES TYPICAL 1KH₂ SIGNAL REQUIRED FOR 10 WATT R.M.S. OUTPUT WITH ALL CONTROLS MAX., AND BOOST OFF.

LDRs: VACTROL VTL5C1

CAUTION: 500 VOLTS AVAILABLE-DISCONNECT POWER SUPPLY AND ALLOW AT LEAST 50 SEC. FOR VOLTAGES TO BLEED OFF BEFORE SERVICING AMPLIFIER.

100 V. 50/60 H₂ MODELS USE SAME HOOKUP EXCEPT TRANSFORMER IS Q18542 & FUSE IS 3A/125 V. MIN.

100 TO 260 VOLTS EXPORT VERSIONS ONLY 50/60 H₂ GROUND SWITCH .047 125 V.A.C. & A.C. RECEPTACLE DELETED FOR EXPORT.

Fender / ROGERS / Rhodes
 CBS MUSICAL INSTRUMENTS & DIVISION OF CBS INC. FULLERTON, CALIFORNIA 92835

PART NAME
SCHEMATIC - CONCERT
 DOMESTIC, EXPORT, JAPAN & CSA

RELEASE	SIZE	PART NO	REV
	D	Q18926	B
SCALE	MODEL NO	CONCERT	

Footswitch for Fender '83 Concert, Twin Reverb II

Red Jack

Tip: -6.2Vdc
Ring: Hi Gain
Shield: Gnd

Plain Jack

Tip: Clean
Ring: Reverb
Shield: Gnd

