


# FENDER "PRO-AMP" SCHEMATIC

## MODEL 5E5

### NOTICE

VOLTAGES READ TO GROUND  
WITH ELECTRONIC VOLTMETER.  
VALUES SHOWN  $\pm$  OR  $- 20\%$



# FENDER "PRO-AMP" LAYOUT

## MODEL 5E5

**NOTICE**  
 VOLTAGES READ TO GROUND  
 WITH ELECTRONIC VOLTMETER.  
 VALUES SHOWN + OR - 20%

