





# Kitty Hawk Quattro Preamp



Relay switches shown in "OFF" state.

- Channel Selector**
- Clean (LEDs off)
  - Crunch (Green LED)
  - Lead (Red LED)
  - Hell (Red+Green Leds)

Ground MUST be isolated from chassis!!!