

SWITCH POSITION	
STD. ROTARY	1
HIGH TREBLE	2
TREBLE	3
MEDIUM	4
BASS	5
CONTRA BASS	6

2401/DB5.