THIS PRODUCT MANUFACTURED UNDER ONE OR MORE OF THE FOLLOWING U.S PATENTS # 2817708, #297368I, #192859 & PATENTS PENDINGS

NORMAL CHANNEL
REVERB CHANNEL
INPUT JACKS (4) 068270
V1A 7025
V1B
V2A 7025
V2B
V3 12AT7
V4 7025
V5 7025
V6A 6L6GC
V6A 12AT7
V6B
V8 6L6GC
V9 5U4GB
017079 D.P.D.T. CHANNEL SWITCH
SWITCH ON BASS CONTROL
017449 999 KHD PREAMP GAIN
PULL SWITCH S1 ON PREAMP GAIN
PULL SWITCH TREBLE
MID BOOST SWITCH ON 017324
REVERB PEDAL JACK 013171
INPUT OUTPUT REVERB UNIT JACKS (2) 021824
P.C. PANEL ASSEMBLY 017488
SYL-ECG-40938 017451
TRANSISTORS 014409 (3)
REVERB LED ON PANEL
NORMAL LED ON PANEL
CHANNEL PEDAL JACK 021824
LEVEL CONTROL 10KA 021899
LINE OUT JACK 021956
FOR 8 OHM OUTPUTS RECONNECT (A) TO GRN AND (B) TO GRN YEL
SPKR. JACK FOR 4 OHM MIN LOAD 068270
EXT. SPKR. JACK FOR 4 OHM MIN. LOAD 014143
017450
022707
022723
TO ALL 6.3 V HEATERS
STAND BY SWITCH 037960
A.C. RECEPT
GROUND SWITCH 010023
A.C. SWITCH 037960
SLO BLO FUSE
120V 60HZ 010766
HUM BALANCE 028421
TO PILOT LAMP
100 50/60HZ MODELS USE SAME HOOKUP EXCEPT TRANSFORMER IS 014955
014955
EXPORT A.C. CORD 013002
A.C. SW. 061663
FUSE 2A/250V
100 TO 260 V EXPORT VERSIONS ONLY (50/60) Hz
GROUND SWITCH .047 125 V A.C. & A.C. RECEPTACLE DELETED FOR EXPOPT.

⬡ DENOTES LEAD CONNECTIONS TO P.C. BOARDS.
5. A,B&C LDR ARE P/N 016752.
4. SIX DIGIT NUMBERS ARE FENDER PART NUMBERS.
△3 USED IN SOME VERSIONS.
2. ALL CAPACITORS 600 V MIN.
1. ALL RESISTORS ½ WATT, ±10%

Fender / Rogers® / Rhodes®
CBS MUSICAL INSTRUMENTS — A DIVISION OF CBS, INC. FULLERTON, CALIFORNIA 92631

PART NAME
SCHEMATIC -30 WATTS DUAL CHANNEL
DOMESTIC, EXPORT AND JAPAN

SIZE	PART NO.	REV
D	017452	